



Enter/Exit programming




1

Return to USB default



2

keyboard language support---French




3

**Penser à redémarrer la machine après avoir scanner les codes barres dans l'ordre**


Message terminator for USB

None



4

Enter/Exit programming



6

EAN-13 first "0" can transmitted



5